


VE.Bus BMS Connection Point



To BP Switch

